



this page is still very messy and early days ...

Essential keyboard shortcuts

- Go to 'the menu'
 - Key: Commodore + restore
- In the menu navigate with the WASD-keys
 - Key: W, A, S, D
- In 'the menu' go to 'advanced settings'
 - Key: F2
- Shutting down the C64 instead of holding down the power button for 4 seconds, when you are 'in the menu'
 - Key: F1 + select '*power and reset*' ⇒ '*shutdown*'

From:

<https://c64u.org/dokuwiki/> - **C64 Ultimate Wiki**

Permanent link:

https://c64u.org/dokuwiki/keyboard_control?rev=1768598000

Last update: **2026/01/16 21:13**

