



this page is still very messy and early days ...

# Essential keyboard shortcuts

Note: C= means the keyboard key with the Commodore logo on it.

## Menu shortcuts

- Go to 'the menu'
  - Key: C= + restore

## While you are in the menu

- Navigate with the WASD-keys
  - Key: W, A, S, D
- Go to 'advanced settings'
  - Key: F2
- Shutting down the C64 instead of holding down the power button for 4 seconds
  - Key: F1 + select '*power and reset*' ⇒ '*shutdown*'
- Swap joystick ports around (port 1 ↔ port 2)
  - *If you want to play a game that uses 'the other port' instead of changing them physically.*
  - Key: C= + J

## While in Basic

- Load first program on disk
  - shift + run/stop

From:

<https://c64u.org/dokuwiki/> - **C64 Ultimate Wiki**

Permanent link:

[https://c64u.org/dokuwiki/keyboard\\_control?rev=1769675220](https://c64u.org/dokuwiki/keyboard_control?rev=1769675220)

Last update: **2026/01/29 08:27**

