

Essential keyboard shortcuts

Note: C= means the keyboard key with the Commodore logo on it.

Menu shortcuts

- Go to 'the menu'
 - Key: C= + restore

While you are in the Ultimate menu

C64U standard keys

Key	Result
F1	Tool Menu
F2	Advanced menu
F3	Page Up
F4	System information
F5	Page down
F6	Online file search
F7	Help
F8	Close Ultimate menu
RUN/STOP	Exit menu

WiFi setup/password special characters

Key/Hotkey	Result
Shift +	{
Shift -	}
Shift £	_
Shift ←	~
Shift ↑	^
←	`
↑	

While in Basic

- Load first program on disk
 - shift + run/stop
- Soft reset without clearing the memory
 - run/stop + restore

GEOS

It is reported that if the mouse does not work C+=i can make a difference

From:

<https://c64u.org/dokuwiki/> - **C64 Ultimate Wiki**

Permanent link:

https://c64u.org/dokuwiki/keyboard_control?rev=1784415300

Last update: **2026/07/18 22:55**

