


TIPS & TRICKS FOR ULTIMATE DEVICES

A selection of quick tips and tricks to make your life with your ultimate device even more fun!

- Experiencing garbled text and/or graphics in a demo or game? Check the TURBO BOOST settings and make sure to have set it to OFF. Even having Turbo set to 'Manual' mode, at only 1 MegaHertz, can throw off the timings needed for these games or demos to be displayed properly.
- CommoServe hack to include 'Assembly64' - See [commoserve_hack_to_include_assembly64](#)
- It has been reported that a USB thumb drive is about 3 times faster than an SD card. So if loading speeds are important to you, use a USB “stick” for loading larger amounts of data



- Did you know that you can play Amiga style .MOD files on your Ultimate device? If you don't have any mod files yet, start at <https://modarchive.org/> and download a .mod file of your liking. IMPORTANT: Only .mod files will work. Other formats, like .xm, .it, .s3m, etc. are not compatible with your Ultimate device.
- If you have software (usually a demo) that refuses to work on your Ultimate device, make sure to do the following:
 - Turn Turbo Boost OFF
 - Set Drive A to 1541 mode
 - Disable Drive B
 - Disable IEC drive
 - Disable IEC printer
 - If using a fastloader (i.e., JiffyDOS), make sure to disable that too.

From:
<https://c64u.org/dokuwiki/> - **C64 Ultimate Wiki**

Permanent link:
https://c64u.org/dokuwiki/tips_tricks

Last update: **2026/08/12 09:48**

