

Finding the right settings

GEOS / REU does not work



There is some doubt of this is actually correct

If you are wanting to use GEOS or any other program that requires the REU, you may need to double check the address for UltiSID 2. Out of the box, UltiSID 2 was at \$DF00, which conflicts with the C64U's built-in REU and causes programs to not see the REU. Instead, I move UltiSID 2 to \$D420, and it now works flawlessly.

- To get there: C64U Menu - Audio Setup - SID Addressing - UltiSID 2 Address.



UltimateChat does not work over WiFi

UltimateChat does not work over WiFi. It came on "The Very Second". It works when connected with Ethernet.

- **You are not alone. No known solution at present.** (if you know one, please edit)

[troubleshooting](#), [GEOS](#), [REU](#)

From:

<https://c64u.org/dokuwiki/> - **C64 Ultimate Wiki**

Permanent link:

<https://c64u.org/dokuwiki/troubleshooting?rev=1768336819>

Last update: **2026/01/13 20:40**

